

# Installation Instructions for PROWITE™ Edge 3 whiteboards with Concealed Split Rail Mounting.

You will need CSK (countersunk) head screws for the wall brackets.  
Refer to the cross-section diagram below.

## Installation Instructions for Edge3™ Whiteboard:

1. Lay the whiteboard face down and sit the wall mount brackets inside the split rail on the back of the Edge3™ frame.
2. Measure down from the top of the whiteboard and mark a level line on the wall where the bottom of the brackets will go for both rails. Find solid fixing points along this line.
3. Screw the brackets to the wall, spaced along the line and into wall studs where possible. Check the wall is flat and pack out the brackets if needed where studs don't align.
4. Hang the whiteboard by sliding it down onto the brackets, ensuring it sits flat and level. Take care not to damage the wall or the painted back surface during installation.

## PROWITE / WITAX WHITEBOARD WITH SPLIT RAIL MOUNTING & 3MM MITRE FRAME - SECTION DETAIL

